

List of parts that are included in your box:

PART NUMBER:	DESCRIPTION:	QTY:
C-501	BASE WITH CASTERS	1
1103	PVC SPACER	1
1104	RUBBER BALL	1
C-506-OP	OUTER POLE	1
C-505	POLE COLLAR	1
C-506-IP	INNER POLE WITH PLUG	1
1308-NP	RAMS HORN	1
C-502	POLE KNOB	1
1609	10/32 X 3/16" SOCKET SCREWS	2
1101S	10/32 X 1/4" SOCKET SCREWS	2
1/4-20X 1/4"	1/4-20X 1/4" SOCKET SCREWS	2
1102S	3/32 HEX KEY	1
1121	1/8 HEX KEY	1

Assembly Instructions:

STEP 1:

- Insert Outer pole into the base, and tighten with 1/8 hex key. Remove IV knob and Collar. Once you have removed Inner pole from Outer pole, insert PVC IV Spacer, and rubber ball.
- Insert Inner pole back into Outer pole. With one hand On the inner pole, slide Collar back in place. Tighten With IV knob.

STEP 2:

- Take a rubber Mallet to make sure the Rams horn is in place.
- Secure the Rams horn on top of the Inner pole using The 3/32 hex key.

ADDING ACCESSORIES TO YOUR IV POLE:

- Remove IV Knob with the 3/32 hex key, and slide the Collar off of the Outer pole and over the inner pole.
- Once Collar is removed completely, slide accessories down the Outer pole.
- Once all accessories are installed, replace the collar and tighten the set screws.

